

X-Stand X-Stand

JR-7X X Banner Stand

60cm x 1.6m

Assemble Instruction:

Weight: 980gm



Step 1



Step 2



Step 3



Step 4



SZ-BXE

Classic Black X Banner

60cm x 1.6m

Weight: 750gm



SZ-EX

Classic Blue X Banner

60cm x 1.6m

Weight: 750gm



SZ-UX

U Shape X Banner

60cm x 1.6m

Weight: 750gm



Assemble Instruction:




Open the X-banner top pole

Prop up the 270 degrees : feet after folding the U foot

Open the X-banner bottom pole

Regulate the size according to the picture size And hook position

Pin up the picture



Revolving the nut and regulates the link or position

Revolving the nut and regulates the size of picture




SZ-PX Premium X Banner
SZ-PX/D Double Side Premium X Banner

60cm – 1.2m x 1.2m – 2.10m
 60cm – 1.2m x 1.2m – 2.10m

Assemble Instruction:

Weight: 1.6 - 2.4k



Install process



1. Push button, could adjustable the angle.




2. Insert B to A.



3. Fix the picture.



4. Finished.





SZ-SX

Skillful X Banner Stand

60cm x 1.6m

Weight: 1.6kg



QSB 160
QSB 180

Premium X Display Stand
Premium X Display Stand

60cm x 1.6m
60cm x 1.8m

Weight: 1 – 1.1kg



JR-17

Table Top X Stand Display

A3

Weight: 250gm

